User Manual Convertible Tablet roda PEGASUS





roda computer GmbH

Landstrasse 6 77839 Lichtenau/Baden Telephone: +49(0)7227/9579-0

Telefax: +49(0)7227/9579-20

roda Service Center Hüllhorst

Bredenhop 20 32609 Hüllhorst

Telephone: +49(0)5744/944-470 Telefax: +49(0)5744/944-475 No part of this publication may be processed; such as reproduced, transmitted, transcribed, stored in a retrieval system, translated into any computer language in any form, or by any means of electronic, mechanical, magnetic, optical, chemical, or others without the prior written permission of the manufacturer.

The manufacturer reserves the right to revise this publication and to make changes to the contents hereof without obligation to notify any person of such revision or changes.

The manufacturer makes no representations or warranties, either expressed or implied, about the contents and specifically disclaims any warranties as to merchantability or fitness for any particular purpose. Any of the software described in this manual is sold or licensed "as is". Should the programs prove defective following purchase, the buyer (and not the manufacturer, its distributor, or its supplier) assumes the entire cost of all necessary servicing, repair and any incidental or consequential damages resulting from any software defects.

Copyright © 2010 roda computer GmbH Lichtenau, January 2010

Author: Joachim Tschan

Version History:

Version	Description	Date	Written by
1.0	Creation	18.01.2010	Joachim Tschan
1.1	Revision	01.04.2010	Christian Fessler

Trademark Acknowledgments

Microsoft, Windows and Windows XP are registered trademarks of Microsoft Corp.

All product and company names are trademarks or registered trademarks of their respective holders.

EMC and Safety Notice

Federal Communications Commission Radio Frequency Interference Statement This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and radiates radio frequency energy and if not installed and used in accordance with the instructions, may cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the supplier or an experienced radio/TV technician for help.

This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Any changes or modifications (including the antennas) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

This equipment complies with FCC RF radiation exposure limits set forth for an un-controlled environment. To maintain compliance with FCC RF exposure compliance requirements, avoid direct contact to the transmitting antenna during transmitting.

Countermeasures if interference occurs

You are encouraged to do the following if interference occurs while you are operating the device:

Turn OFF the unit and unplug the AC adapter from the outlet to see if the interference disappears.

Connect the AC adapter to the outlet in another room and check if the interference still exists.

Use an outlet that is far away from the interfered appliance.

Re-orient your computer in respect to the interfered appliance to see if there is improvement.

If all of these failed, please call your supplier for help.

CE

This equipment complies with the requirements set out in the Council Direction on the Approximation of the laws of the Member States relating to Electromagnetic Compatibility (89/336/EEC). For the evaluation regarding the electromagnetic compatibility, the following standards were applied:

Standards	Specifications and Parameters
EN 301 489-17 1.2.1 ERM (electromagnetic compatibility and radio spectrum matters):EMC (electromagnetic compatibility) standards for radio equipment and service-Part 17: Specific conditions for wideband data and Hiperlan equipment EN301 489-01 V1.4.1 (EMC standard for radio equipment), ETSI EN 300 328 V1.6.1 (2004-11), (EMC standard for	EN55022 +A2: 2003 Class B EMI Conduction and Radiation; EN61000-3-2 Harmonics EN61000-3-3 +A1: 2001 Flicker (Voltage fluctuation) EN55024 EMS; EN61000-4-2 +A2: 2001 ESD (Electrostatic discharge); EN61000-4-3 +A1: 2002 RS (Radio frequency electromagnetic field) EN61000-4-4 +A2: 2001 EFT (Electrical fast transient/burst); EN61000-4-5 +A1: 2001 Surge EN61000-4-6 +A1: 2001 CS (Conducted disturbances induced by radio frequency); EN61000-4-8 Power-
using spread spectrum modulation techniques), ETSI EN301 511 V9.0.2 (2003-03) (GPRS)	Frequency Magnetic Field; EN61000-4-11 +A1: 2001 Voltage Dips and Voltage Interruptions EN60950: 2001 Safety of Information Technology Equipment

UL, TÜV

AC Adapter (EN60950 LVD is included in TÜV)

Environmental Information, Material Safety and Recycling

Caution: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

All materials used in the construction of this equipment are recyclable or environmentally friendly. Please recycle the packing materials, and at the end of the product's life, all other materials by local regulations. Please refer "Material and Recycling" for the contents of the materials.

- The equipment may still contain tiny amount of hazardous substances for health and environment, though those are below control level.
- To avoid spreading such substances into the eco system, and to minimize the pressure on the natural, you are encouraged to use the appropriate take-back. Those will reuse or recycle most of the materials in a sound way after end life.
- The crossed bin symbol indicates proper disposal is required.
- For more information on collection, reuse and recycling, please consult local or regional waste administration.
- You can also contact the supplier for more information on the environmental details of the equipment.

Table of contents

1	GET	TING STARTED	9
	1.1	System Configurations	10
	1.2	Preparing your 13.3" Rugged Notebook Pegasus	11
2	COM	IPONENTS AND FUNCTIONS	13
	2.1	Front View	13
	2.2	I/O Port View	14
	2.3	Stylus	14
	2.4	Making Connections	15
	2.4.1	USB (Universal Serial Bus) Ports	15
	2.4.2	LAN Port	15
	2.4.3	Modem Port	15
	2.4.4	Microphone-in Jack	15
	2.4.5	RS232 Port	15
	2.4.6	Audio-out Jack	15
	2.4.7		
	2.4.8		16
	2.4.9		
	2.4.1	0 PC Card Slot	16
	2.4.1		
	2.4.1	2 Display output	16
	2.5	Power System	
	2.5.1	5	
	2.5.2		
	2.5.3		
	2.5.4	, , , , , , , , , , , , , , , , , , ,	
	2.5.5		
3	Main	tenance / Service	
	3.1	Troubleshooting	
	3.2	Service	
	3.2.1	Service Supply Note	22
	322	Downloads	23

GETTING STARTED



1 GETTING STARTED

Congratulations on your purchase of a Pegasus 13.3" rugged notebook. The 13.3" rugged notebook Pegasus is a fully functional PC with built-in wireless connectivity. You will be able to organize and access important business and personal information. In addition, you will be able to send and receive e-mail and access the Internet.

This Manual contains all the information you need to set up and use your 13.3" rugged notebook. It describes all the features of the 13.3" rugged notebook in an easy-to-read yet thorough manner.


1.1 System Configurations

- Processor: Intel U7500" Merom" Processor Support
 - ◆ Speed at 1.06GHz
- Chipset: INTEL ICH-8M + 965GM Chipset
- OS Support:
 - Microsoft Windows XP Edition OS Support
- Display Screen Interface Support:
 - Standard Touch Screen
 - Sunlight readable screen
- LCD Flat Panel Support:
 - 13.3" TFT,1280x800 Resolution,
- Storage Support:
 - ♦ HDD Support
 - 2.5" SATA HDD
 - Capacity Points: 80GB 5400rpm (up to 250GB)
- System Memory:
 - Single SO-DIMM Memory Slots
 - ◆ DDR2-667MHz
 - System Memory Upgradeable to 2GB
- Expansion Slot:
 - connecter
 - ♦ USB 2.0 support
 - ♦ RS-232 support
 - ◆ PCMCIA & Flash memory slot
- Optical Device
 - ◆ DVD S-MUTI DL 8X/6X/4X
- Communication Devices Support:
 - ♦ Wireless LAN (WLAN) Intel 802.11A/B/G/N support:
 - ♦ Modem 56K
 - ◆ Bluetooth 2.1 + EDR
 - GPS
 - WWAN compliant

1.2 Preparing your 13.3" Rugged Notebook Pegasus

These are only quick instructions for using your 13.3" rugged notebook. Read the later pages for detailed information on using your 13.3" rugged notebook.

1. Connect the AC Power Adapter



2. Install the battery pack



3. Turn ON the 13.3" Rugged Notebook



IMPORTANT! When opening, do not force the display panel down to the table or else the hinges may break! Never lift the 13.3" rugged note-book by the display panel!

Ш

COMPONENTS AND FUNCTIONS

2 GETTING STARTED


2.1 Front View



- 1. Five Way Control Key Up/Down , Left/Right & Enter Button
- 2. WiFi/BT Trigger Button
- mouse button
- 4. Power Button
- 5. LCD Panel
- 6. Internal Microphone & Speaker
- 7. LED Status Indicator
- 8. Finger print
- 9. Volume control
- 10. Brightness control

PEGASUS User Manual roda

2.2 I/O Port View



1	USB port	5	RS232 port	9	Kensington lock
2	LAN port	6	Display output	10	MIC in & Headphone out
3	Modem port	7	Optical drive	11	PCMCIA and flash memory
4	USB port	8	Battery Slot	12	Power (DC) input

2.3 Stylus



2.4 Making Connections

Your 13.3" rugged notebook Pegasus is equipped with a full array of ports and connectors, including standard input/output (I/O) ports for quickly and easily adding peripheral devices such as printers, keyboards, and mice. Refer to documentation included with individual devices for details on connecting these devices to your 13.3" rugged notebook

2.4.1 USB (Universal Serial Bus) Ports

The Universal Serial Bus (USB) is the latest standard for attaching monitors, input devices, scanners, and other devices to a PC. USB devices can be chained together on a single cable.

2.4.2 LAN Port

The RJ-45 LAN port with eight pins is larger than the RJ-11 modem port and supports a standard Ethernet cable for connection to a local network. The built-in connector allows convenient use without additional adapters

2.4.3 Modem Port

The RJ-11 modem port with two pins is smaller than the RJ-45 LAN port and supports a standard telephone cable. The internal modem supports up to 56K V.90 transfers. The built-in connector allows convenient use without additional adapters.

2.4.4 Microphone-in Jack

Connect a microphone to this jack to record audio.

2.4.5 RS232 Port

The Connector is reserved for specific purpose which is used to connect to customer's device.

2.4.6 Audio-out Jack

Connect a stereo headset or external speakers to this jack to listen to multimedia.

2.4.7 DC-in Jack

Connect the DC power cable from the AC adapter to this jack.

2.4.8 Optical Drive

The Notebook PC comes in various models with different optical drives. The Notebook PC's optical drive may support compact discs (CD) and/or digital video discs (DVD) and may have recordable (R) or re-writable (RW) capabilities. See the marketing.

2.4.9 Kensington® Lock Port

The Kensington® lock port allows the Notebook PC to be secured using Kensington® compatible Notebook PC security products. These security products usually include a metal cable and lock that prevent the Notebook PC to be removed from a fixed object. Some may also include a motion detector to sound an alarm when moved.

2.4.10 PC Card Slot

One PCMCIA 2.1 compliant PC card socket is available to support on type I/II PC card. The socket supports 32-bit card Bus. This allows accommodation of Notebook/PC expansion options such as memory cards, ISDN, SCSI, and Smart Cards adapters.

2.4.11 Flash Memory Slot

Normally an external memory card reader must be purchased separately in order to use memory cards from devices such as/ digital cameras, MP3 players, mobile phones, and PDAs. This Notebook PC has a built-in high-speed memory card reader that can conveniently read

2.4.12 Display output

The 15-pin D-sub monitor port supports a standard VGA-compatible device such as a monitor or projector to allow viewing on a larger external display.

GPS Disclaimer

Underwriters Laboratories Inc. ("UL") has not tested the performance or reliability of the Global Positioning System ("GPS") hardware, operating software or other aspects of this product. UL has only tested for fire, shock or casualties as outlined in UL's Standard(s) for Safety.UL60950-1 Certification does not cover the performance or reliability of the GPS hardware and GPS operating software. UL MAKES NO REPRESENTATIONS, WARRANTIES OR CERTIFICATIONS WHATSOEVER REGARDING THE PERFORMANCE OR RELIABILITY OF ANY GPS RELATED FUNCTIONS OF THIS PRODUCT.

2.5 Power System

2.5.1 Using AC Power

The Pegasus power is comprised of two parts, the power adapter and the battery power system. The power adapter converts AC power from a wall outlet to the DC power required by the 13.3" Rugged Notebook. Your 13.3" Rugged notebook comes with a universal AC-DC adapter. That means that you may connect the power cord to any 100V-120V as well as 220V-240V outlets without setting switches or using power converters. Different countries may require that an adapter be used to connect the provided US-standard AC power cord to a different standard. Most hotels will provide universal outlets to support different power cords as well as voltages. It is always best to ask an experienced traveler about AC outlet voltages when bringing power adapters to another country.



TIP: You can buy travel kits for the 13.3" rugged notebook that includes power and modem adapters for almost every country.

With the AC power cord connected to the AC-DC converter, connect the AC power cord to an AC outlet (preferably with surge-protection) and then connect the DC plug to the 13.3" Rugged Notebook. Connecting the AC-DC adapter to the AC outlet first allows you to test the AC outlet's power and the AC-DC converter itself for compatibility problems before connecting the DC power to the 13.3" Rugged Notebook. The power indicator on the adapter (if available) will light if the power is within accepted ranges.

IMPORTANT! Damage may occur if you use a different adapter to power the 13.3" Rugged notebook or use the 13.3" rugged notebook's adapter to power other electrical devices. If there is smoke, burning scent, or extreme heat coming from the AC-DC adapter, seek servicing. Seek servicing if you suspect a faulty AC-DC adapter. You may damage both your battery pack(s) and the 13.3" rugged notebook with a faulty AC-DC adapter.



NOTE: This Pegasus notebook may come with either a two or threeprong plug depending on territory. If a three-prong plug is provided, you must use a grounded AC outlet or use a properly grounded adapter to ensure safe operation of the 13.3" rugged Notebook.

WARNING! THE POWER ADAPTER MAY BECOME WARM TO HOT WHEN IN USE. BE SURE NOT TO COVER THE ADAPTER AND KEEP IT AWAY FROM YOUR BODY.

2.5.2 Using Battery Power

The Pegasus is designed to work with a removable battery pack. The battery pack consists of a set of battery cells housed together. A fully charged pack will provide several hours of battery life, which can be further extended by using power management features through the BIOS setup. Additional battery packs are optional and can be purchased separately through a 13.3" Rugged notebook retailer.

2.5.3 Installing and Removing the Battery Pack

Your 13.3" rugged notebook may or may not have its battery pack installed. If your Pegasus does not have its battery pack installed, use the following procedures to install the battery pack.



IMPORTANT! Never attempt to remove the battery pack while the 13.3" rugged notebook is turned ON, as this may result in the loss of working data.

2.5.4 To remove the battery pack:



IMPORTANT! Only use battery packs and power adapters supplied with this 13.3" rugged notebook or specifically approved by the manufacturer or retailer for use with this model or else damage may occur to the 13.3" rugged notebook.



2.5.5 Battery Care

The 13.3" rugged notebook's battery pack, like all rechargeable batteries, has a limit on the number times it can be recharged. The battery pack's useful life will depend on your environment temperature, humidity, and how your 13.3" rugged notebook is used. It is ideal that the battery be used in a temperature range between -20°C and 60°C. You must also take into account that the 13.3" rugged notebook's internal temperature is higher than the outside temperature. Any temperatures above or below this range will shorten the life of the battery. But in any case, the battery pack's usage time will eventually decrease and a new battery pack must be purchased from an authorized dealer for this 13.3" rugged notebook. Because batteries also have a shelf life, it is not recommended to buy extras for storing.





MAINTENANCE / SERVICE



. Д

∢ ⊤

C

3 Maintenance / Service

3.1 Troubleshooting

Should the computer fail to function properly, the troubleshooting steps below may be followed. (Please backup your data before troubleshooting)

- Check AC adapter, battery, and the power source.
- Press reset to re-boot the computer.
- Remove the software suspected.
- Press hard reset to re-boot the computer.

3.2 Service

If troubleshooting steps are unsuccessful, consult your supplier for RMA. If troubleshooting steps are unsuccessful, consult your supplier for service. If they can not help you please call roda Service Center.

Service address:	Service:	
roda computer Center	Monday – Thursday	8:30 am - 12:30 pm
Bredenhop 20	&	1:00 pm - 4:30 pm
32609 Hüllhorst	Friday	8:30 am - 12:30 pm
	&	1:00 pm - 3:00 pm
Phone: +49 5744-944 470		
Fax: +49 5744-944 475		
E-Mai: support@roda-computer.com		

Note: The roda Service Center needs a detailed description of the problem and the serial number of the device.

If it is necessary to send in your computer for repairs, you can download a service waybill (Service Supply Note) on the roda homepage (www.roda-computer.com), which you have to fill in.

3.2.1 Service Supply Note

Include this sheet with the following information:

Name

Address

Serial number, Customer number, Article number

Place and date of purchase or the original invoice number

Date of failure

A DETAILED description of the problems you have encountered A list of the hardware/ software configuration, if applicable

Service - Begleitschein Ditte prüfen Gie vor der Rücksendung gründlich, ob tetsächlich ein Defekt vorliegt! Sollte unsererseits an dem eingesandten Gerät kein Fehler festgestellt werden, berechnen wir eine Test- und Bearbeitungspauschale, die 10% des Werenwertes, mindetens aber 66.5, netto beträgt roda computer GmbH Absender: Service-Abteilung Bredenhop 20 Strasse: PLZ/Ort: 32609 Hüllhorst Datum der Rücksendung: Vom roda - Geschäftspartner auszufüllen Garantiefall (Anerkennung nur mit Nachweis) Kostenpflichtig Folgende Geräte werden zurückgesandt: Anzahl roda-Artikel Nr. Rechnungs-Nr. Rechnungs - Datum Seriennummer:__ Bitte nennen Sie hier ausführlich den Grund der Rücksendung: Mitgeliefertes Zubehör Ansprechpartner für Rückfragen (+Durchwahl): eMail-Adresse des Ansprechpartners: Von roda computer auszufüllen Mitgeliefertes Zubehör: Verpackung außen: Beschädigungen: Bemerkungen: Datum: ____ Bearbeitet: ____ Werkstattauftrag/KV: EK_LH_7.2.3_5_03

Figure 1: Service Supply Note (German Version)

3.2.2 Downloads

Check our website (www.roda-computer-com) for downloads:

- Updates
- Drivers
- Manuals
- Service Supply Note